



Model O2T Warning & Alarm Messages

4.3 Warning and alarm messages

The various warning and alarm messages generated by the instrument are described below:

Warnings	Meaning of Messages
Warm-up..	Warning: Sensor warm-up and stabilization
CAL Err!	Alarm: calibration error
Lo bat	Low battery warning
Err: CKS	Sensor failure, memory checksum
Err: COP	Sensor failure, system watchdog
Err: CFG	Sensor failure, cell configuration checksum
Err: TEC	Sensor failure, laser temperature control
Err: REF	Low laser power
Err: NUL	Cell null balance
Err: IO2	Invalid oxygen computation